



DRILLING FLUIDS EQUIPMENT

For over 30 years OFI Testing Equipment (OFITE) has provided instruments and reagents for testing drilling fluids, well cements, completion fluids, and wastewater. In addition to these product lines we also offer a range of instruments for core analysis. From our manufacturing facility in Houston, TX we provide customers all over the world with quality products and exceptional service.

Our drilling fluids product line includes innovative designs such as the Model 900 Viscometer, which showcases our ability to develop new technology to meet customer and industry demands. We also offer Retorts, Aging Cells, Roller Ovens, Mud Balances, Filter Presses, and all other instruments required to evaluate drilling fluid properties according to API Recommended Practice 13B-1 and 13B-2.

As an independent manufacturer and supplier, OFITE has one priority, our customers.

OFI TESTING EQUIPMENT, INC.
11302 Steeplecrest Dr.
Houston, TX 77065
877.837.8683
www.ofite.com
© Copyright OFITE 2015



Automatic Pressure Control System for PPT

The Automatic Pressure Control System can provide and maintain a constant pressure on up to four Permeability Plugging Testers. It consists of two air-driven pumps and four hydraulic, self-venting regulators. Replacing the manual hand pump, the air-driven pump automatically engages when you start the test and maintains a constant pressure for the duration.



Features

- Incorporates pressure relief valves for safety
- Maintains constant pressure

Technical Specifications and Requirements

- #171-89 4,000 psi
- #171-89-6K 6,000 psi

Specifications

- Pressure medium: hydraulic fluid

Requirements

- Air Supply: 130 psi