

Poly Prep 'N Floc Test Kit

Brand: OFI Testing Equipment, Inc.

Product Code: 291-00

Availability: Call for availability

Lead Time: 60



Description

The Poly Prep 'N Floc Test Kit allows field personnel to properly prepare water soluble flocculants/coagulants and observe their effects on the type of fluid or sludge in use. The Poly Prep 'N Floc is ideal for quickly selecting the proper polymer and dosage for sludge dewatering and water/wastewater treatment. The test kit includes a balance and low shear stirrer to accurately weigh and dissolve polymers. A stainless steel rack contains four transparent cylinders and stoppers to observe floc characteristics and water clarity after each dose and inversion.