


HI 758 Marine Calcium



Dear Customer,

Thank you for choosing a Hanna Instruments Product.

Please read this instruction manual carefully before using the instrument. If you need additional technical information, do not hesitate to e-mail us at tech@hannainst.com.

Preliminary examination:

Please examine this product carefully. Make sure that the instrument is not damaged. If any damage occurred during shipment, please notify your Dealer. Each HI 758 meter is supplied complete with:

- Two Sample Cuvettes and Caps
- Reagents for 25 tests
- Dropper
- 2 x 1 mL syringes with tips
- 1 x 1.5V AAA Battery
- Instruction Manual




For more details about spare parts and accessories see "Accessories".

Technical specifications:

Range	200 to 600 ppm
Resolution	1 ppm
Accuracy	± 6 % of reading @ 25 °C / 77 °F
Light Source	Light Emitting Diode @ 610 nm
Light Detector	Silicon Photocell
Method	Adaptation of the zincon method.
Environment	0 to 50 °C (32 to 122 °F); max 95% RH non-condensing
Battery Type	1 x 1.5V AAA
Auto-Shut off	After 10 minutes of non-use
Dimensions	81.5 x 61 x 37.5 mm (3.2 x 2.4 x 1.5")
Weight	64 g (2.25 oz.)

Functional description:



1. Cuvette cap.
2. Cuvette with cap.
3. Cuvette holder.
4. Liquid Crystal Display.
5. Button

Errors and warnings:



Light High: There is too much light to perform a measurement. Please check the preparation of the zero cuvette.



Light Low: There is not enough light to perform a measurement. Please check the preparation of the zero cuvette.



Inverted cuvettes: The sample and the zero cuvette are inverted.



Under range: A blinking "200" indicates that the reading is under range.



Over Range: A blinking value of the maximum concentration indicates the reading is over range. Dilute the sample and re-run the test.



Battery low: The battery must be replaced soon.



Dead battery: This indicates that the battery is dead and must be replaced. Once this indication is displayed, normal operation of the instrument will be interrupted. Change the battery and restart the meter.

